

**Tractor Pull  
Morrison County Fair -  
Little Falls, MN**

**Saturday, July 26 at 10 a.m.  
(Must pre-register by  
July 19th - no exceptions)**

Contact Persons: Richard Nelson (320) 632-0984 or  
Vic Scherping (320) 547-2170

Class registration is \$15.00 per hook.

- Mail Registration to: Richard Nelson at 19756 125th Ave., Little Falls, MN 56345.

**I. Farm Stock Division, 1959 and Older - Trophies Only in Each Class - 1st, 2nd, 3rd. Weight class: Listed below.**

**II. King of the Hill - \$100 for First in Each Class - Plus a Trophy.**  
Weight Class: 4500, 6000.

**General Rules**

- Tractor must be operated in a safe manner at all times.
- Driver must be 18 years of age or at least 16 years of age with parent's written consent.
- Same tractor may pull in more than one division. Limit of two entries per tractor.
- Driver must be seated in a safe manner when pulling or will be disqualified.
- Driver must observe the flagman and clutch immediately on the red flag or will be disqualified.
- When hooking and unhooking from the weight transfer, tractor must be in neutral and the driver's hands must be free of the tractor.
- Tractors will weigh before pulling when a portable scale is present.
- Tractor must have hitch hole or quarter turn clevis at least 3 inches in diameter. Pulling point not more than 20 inches high and at least 18 inches behind center of axle.
- Any parts falling off the tractor after being hooked and until the tractor is unhooked will result in disqualification.
- Next puller must be on deck and ready to pull.
- Full pulls and ties will re-pull.
- All weights must be in solid form and securely fastened to the tractor on brackets, not on three point hitches.
- Stock model block numbers or replacement blocks, ONLY.
- No homemade manifolds.
- Original type or carburetor that came with the tractor.
- Any questionable age of tractor must have serial number intact and not tampered with.
- All original major parts must be intact: hoods, radiators, fenders, front ends, etc.
- Side shields must be removable.
- Gas, diesel, or LP fuels only. No alcohol or nitrous oxide fuels may be used in tractors. Tractors manufactured to use diesel fuel cannot be converted to gas or LP. Tractors will be naturally aspirated—no fuel injection or gas under pressure is allowed unless tractor equipped. (Example: LP tractors). Electric fuel pumps are allowed with a needle and seat in carburetor.
- Pull will terminate if contestant runs out-of-bounds.
- Promoters reserve the right to refuse any entry.
- Tractors must weigh within weight class before next class starts.
- Tire Specs:  
**0-4500# class: 170 sq. in max**  
13.6 x 38 = 168 sq in  
14.9 x 28 = 170 sq in  
16.9 x 34 = 229 sq. in

**4501-6500# class: 229 sq in max**

14.9 x 38 = 200 sq in

15.5 x 38 = 189 sq in

18.4 x 28 = 250 sq in

**6501 and above # class: 300 sq in max**

18.4 x 38 = 300 sq in

16.9 x 38 = 252 sq. in

- Driver must be present at drivers meeting.

Farm Stock Division 1959 and Older

Weight Classes

2500

3000

3500

4000

5000

6000, 7000, 8000, 9000, 10,000, 11,500

**Prizes:** Trophies will be awarded to 1st, 2nd and 3rd places in each weight class. No 50% payback in this division.

**Rules:**

- Tractors in this division must be stock appearing.
- Low gear only. Tractor with creeper gear can use second gear. No shifting of torque amplifiers.
- Must have stock block, crankcase, head, manifolds, carburetor, exhaust and air cleaner for that model.
- Tractors registered for this class will be dyno checked for HP and RPM.
- RPM limited to Stock Factory high idle + or -2%. Must have positive throttle stop. No use of vise grips for stop.
- Tractors must have working PTO. Tractors with non-working PTOs or that have factory PTOs removed will have to pull in the Farm Hobby Stock Division 1959 and Older.
- Tractors not manufactured with PTOs are eligible to pull in this class subject to pull officials approval.
- Weights must be stock appearing and in factory mounted positions only—no suitcase weights.
- Tires may or may not contain a liquid solution.
- Front and rear wheels and tires must be OEM type for that model tractor.
- Wheel diameter must be stock. Tire size must not exceed class limits. No cut, grooved or radial tires.
- Tractor must run on fuel it was originally equipped for. No high octane gasoline.
- No pulling hitches allowed, must have stock draw bar in stock mounting position and provide your own 3 inch clevis.

**King of the Hill**

**Weight Classes**

4500

6000

**Prizes:** \$100 cash and trophy for 1st place only in each weight class.

**Rules:**

- No RPM limit.
- May use any gear.
- No turbo or superchargers unless originally equipped.
- No aluminum frame or chassis components. Aluminum weight brackets and front wheels allowed.
- No cut, grooved or radial tires. No duals. No front wheel assist.
- Engine must run on gasoline or diesel fuel. Intake manifold must be cast iron-agricultural type.
- Carburetor must be an agricultural carburetor with original draft direction.
- Engine block and crankcase must be same length, height, number of cylinders and make as stock.
- Hitch must be rigid in all directions. No pulling from two or three point hitches. Pulling hitches allowed.